

Mechanical Doorbell Installation Instructions:

Thank you for purchasing one of our beautifully crafted antique reproduction mechanical doorbells. Each bell is hand assembled and tested to ensure you years of trouble free use.

You will require a screwdriver and a keyhole saw to carry out the installation. First decide the height on the door where you would like to position the doorbell lever. Then drill a 1" diameter hole completely through the door and affix the doorbell operator.

Look closely at the back of the doorbell for a moment. The way you mount the doorbell, up or down will affect whether the lever will require a pull or push motion to operate.

You have two setup options for installing the bell to the inside of your door. For Option A attach the bell directly opposite the doorbell operator. It will require some adjustments on your behalf because not all doorbell operator levers are of the same height. Therefore you will need to adjust the doorbell up or down a small amount to allow enough space for the lever to have full movement and for the bell spring mechanism to return to its ready position. When you have finalized the doorbell position secure it with the supplied screws.

Option B is the offset doorbell. With doorbell operator already attached turn your attention to the inside of the door. Offset the doorbell approximately 4" above the doorbell operator lever and secure it. Mount the hole cover. Next, remove the doorbell from its housing by unscrewing it counter-clockwise. Attach one end of the chain by looping it through the eyehole and securing it with a connector. Repeat the procedure for the other end of the chain on the doorbell operator lever. Finally, reattach the bell and ring in your first guests.

